

HI 98509 (Checktemp®1)

Instruction Manual





Hanna Instruments Inc. 584 Park East Drive Woonsocket, RI 02895

www.hannainst.com



sale@ponpe.com www.ponpe.com

Thank You!

Thank you for choosing a Hanna Instruments product. Please read this instruction manual carefully before using the instrument. For additional information, visit www.hannainst.com or e-mail us at tech@hannainst.com.

Specifications	
Range	-50.0 to 150.0 °C / -58.0 to 302 °F
Resolution	0.1 °C (-50.0 to 150.0 °C) 0.1 °F (-58.0 to 199.9 °F)/1 °F (above 200 °F)
Accuracy	$ \begin{array}{l} \pm 0.2 ^{\circ}\mathrm{C}(\text{-}30.0\ to\ 120.0\ ^{\circ}\mathrm{C}) \\ \pm 0.3 ^{\circ}\mathrm{C}(\text{outside:} \text{-}50.0\ to\ -}30.0 ^{\circ}\mathrm{C}\text{and}120.0\ to\ 150.0 ^{\circ}\mathrm{C}) \\ \pm 0.5 ^{\circ}\mathrm{F}(\text{-}22.0\ to\ 199.9 ^{\circ}\mathrm{F}) \\ \pm 1 ^{\circ}\mathrm{F}(\text{outside:} \text{-}58.0\ to\ \text{-}22.0 ^{\circ}\mathrm{F}\text{and}200\ to\ 302 ^{\circ}\mathrm{F}) \end{array} $
Probe	stainless steel, 1 m (3.3') cable
Environment	-30 to 50 °C (-22 to 122 °F)
Battery Type	3 x 1.5 V AAA alkaline
Battery Life	approx. 2 years
Auto Off	8 min (default), 60 min or OFF
Dimensions	107 x 59 x 17 mm (4.2 x 5.3 x 0.7")
Weight	130 g (4.6 oz.)
Certification	${\tt EN13485:2001 - Suitability: Storage; Environment: E; \ Accuracy Class: 0.5; \ Protection: IP65}$

Operation

Turn Checktemp®1 ON: all LCD segments are displayed for 1 second. CalCheck® starts automatically to verify that Checktemp®1 is still accurate to its specifications. A message of "CAL" and "-O-" means that Checktemp1 ® is within specifications. You can now start using Checktemp®1. If CalCheck® displays the "Err" message while measuring temperature, remember that:

- $\cdot\,$ The temperature sensor is located at the tip of the stainless steel probe.
- · It is necessary to wait for a few seconds for the display to stabilize.



Meter Setup

Enter Setup to change between Temperature Unit and to adjust the Auto Shut Off time. To enter the Setup MODE, press the **SET** button located inside the battery compartment once for Temperature Unit or twice for Auto Shut Off.

To enter the Setup mode, remove battery cover and press SET button. The display will show the current temperature unit (E.g. "°C"). Then:

- Use the **ON/OFF** button to switch between "oC" or "oF". Press **SET** once to save.
- Use the **ON/OFF** button to cycle through the following Auto Shut Off options: 8 minutes ("**d08**", default value), 60 minutes ("**d60**"), OFF ("**d--**"). Press the **SET** button once to save.







Battery Replacement

Replace the battery when the battery symbol is blinking or when Checktemp @1 does not turn on. Open the compartment and replace the three AAA batteries, while paying attention to their polarity. Close battery cover.

Note: Batteries should only be replaced in a safe area using the battery type specified in this instruction manual. Old batteries should be disposed in accordance with local regulations.

REAR





Warranty

Checktemp®1 is guaranteed for a period of one year after date of purchase against defects in workmanship and materials when used for their intended purpose and maintained according to instructions. This warranty is limited to repair or replacement free of charge. Damage due to accidents, misuse, tampering or lack of prescribed maintenance is not covered. If service is required, contact your local Hanna Office. If under warranty, report the model number, date of purchase, serial number and the nature of the problem. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the instrument is to be returned to Hanna instruments, first obtain a Returned Goods Authorization number from the Technical Service department and then send it with shipping costs prepaid. When shipping any instrument, make sure it is properly packed for complete protection.

Recommendations for Users

Before using Hanna Products, make sure that they are entirely suitable for your specific application and for the environment in which they are used Operation of these instruments may cause unacceptable interferences to other electronic equipment, thus requiring the operator to take all necessary steps to correct such interferences. Batteries should only be replaced in a safe area using the battery type specified in this instruction manual. Any variation introduced by the user to the supplied equipment may degrade the instrument's EMC performance. To avoid damages or burns, do not put the instrument in microwave oven. For yours and the instrument safety do not use or store the instrument in hazardous environments.

All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner, Hanna Instruments Inc., Woonsocket, Rhode Island, 02895, USA.

IST98509 09/14

sale@ponpe.com www.ponpe.com